



# Replaces Jacobsen LF-3800 Parts

Traction Unit  
Traction Unit



All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



# Replaces Jacobsen LF-3800 Parts

Traction Unit

Traction Unit



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
<b>Filters</b>					
10	<b>RX7000043081</b>	2500809, 555405	Kubota Filter - Fuel	1	
10	<b>RRF10516</b>		SilverGuard Fuel Filter	1	
11	<b>R557772</b>	557772	Baldwin Hydraulic Filter - Return	1	
11	<b>RRF10616</b>	557772	SilverGuard Oil Filter	1	
12	<b>RRF10627</b>	2811255, 556418	SilverGuard Oil Filter - Hydraulic	1	
12	<b>R556418</b>	2811255, 556418	Baldwin Oil Filter - Hydraulic	1	
13	<b>RRF10520</b>		SilverGuard Fuel Filter	1	
13	<b>R18-1520</b>	5001182	Baldwin Fuel Filter	1	
14	<b>R5000919</b>	4114746, 5000919	Baldwin Air Filter Element	1	
14	<b>RRF10143</b>	4114746, 5000919	SilverGuard Air Filter Element	1	
15	<b>RX1627132090</b>	2810346, 557759	Kubota Filter - Oil	1	
<b>Hoses</b>					
40	<b>R132038</b>	132038	Hydraulic Hose Assy	4	
40	<b>R132045</b>	132045	Hydraulic Hose Assy	1	
40	<b>R132060</b>	132060	Hydraulic Hose Assy	1	
40	<b>R132066</b>	132066	Hydraulic Hose Assy	1	
40	<b>R132067</b>	132067	Hydraulic Hose Assy	1	
40	<b>R132069</b>	132069	Hydraulic Hose Assy	1	
40	<b>R132090</b>	132090	Hydraulic Hose Assy	1	

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



# Replaces Jacobsen LF-3800 Parts

Traction Unit

Traction Unit



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
40	<b>R132145</b>	132145	Hydraulic Hose Assy	1	
40	<b>R132161</b>	132161	Hydraulic Hose Assy	1	
40	<b>R364961</b>	364961	Hydraulic Hose Assy	1	
40	<b>R364962</b>	364962	Hydraulic Hose Assy	1	
40	<b>R364968</b>	364968	Hydraulic Hose Assy	1	

## Gauges and Controls

50	<b>RXR140151350</b>	5001305	Kubota Fuel Pump - Electric	1	
51	<b>R162723</b>	162723, 358825	Meter - Hour	1	
52	<b>R27-2360</b>	1000348, 131095	Switch - Key 6 Lead 9/16 Mount	1	
53	<b>R343060</b>	343060, 5000039	Ignition - Key Set/2	1	
54	<b>R151541</b>		Delta Seat Switch - Twist Mount 1 Pole Normally Open	1	
55	<b>R92-6282</b>	554390	Switch - Kill - Seat	1	

## Other Parts Available

56	<b>R500596</b>	500596	Tapered Bearing Set - Cup and Cone	2	
57	<b>R254-94</b>	313089	Tapered Bearing Cone	2	
58	<b>R254-72</b>	313456	Cup - Bearing	2	
60	<b>R132032</b>	132032	Hydraulic Cylinder	3	
61	<b>R132033</b>	132033	Hydraulic Cylinder	2	
62	<b>R501307</b>	501307	Brake Assy	2	

*Tech Note: Includes: 2ea: R353868 Spring; 1 ea: R130191 Plate, R353869 Spring, R501150 Shoes, R546516 Camshaft & R554526 Lever:*

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



# Replaces Jacobsen LF-3800 Parts

Traction Unit

Traction Unit



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
63	<b>R554526</b>	501151, 554526	Lever - Brake	2	
64	<b>R353868</b>	353868	Spring - Shoe Hold Down	4	
65	<b>R130191</b>	130191	Plate - Brake Support	2	
66	<b>R546516</b>	546516	Camshaft - Brake	2	
67	<b>R501150</b>	501150	Shoe - Brake Set / 2	2	
68	<b>R353869</b>	353869, 555714	Spring - Shoe Return	2	
69	<b>R207467</b>	207467	Drum - Brake	2	
70	<b>R311870</b>	311870	Spring - Compression	1	
71	<b>R3008593</b>	3008593	Shaft - Down Pressure	1	
72	<b>R348856</b>	348856	Clamp - Muffler - 1-1/2	2	
73	<b>R361850</b>	361850	Bearing - Fan	1	
74	<b>R315296</b>	315296	Bushing - Pivot Housing	4	
75	<b>R353914</b>	353914	Bolt - Wheel	8	
76	<b>R303962</b>	303962	Stud - Throttle Wire	1	
77	<b>R232-27</b>	232-27, 360111	Stem - Valve w/ Cap	1	
78	<b>RMXB200GY</b>	1001774, 66172	Milsco Seat XB200 - Grey	1	
<i>Tech Note: This seat will not accept seat belts:</i>					
79	<b>R366768</b>	366768	Knob - Black Rubber	1	
80	<b>R1003047</b>	1003047	Cable Assy - Brake	1	
80	<b>R1003048</b>	1003048	Cable Assy - Brake	1	
81	<b>R93-5265</b>	366879	Mount - Engine	3	

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



# Replaces Jacobsen LF-3800 Parts

*Traction Unit*

*Traction Unit*



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
82	<b>R455004</b>	455004	Washer - Flat 1 in SAE	10	
83	<b>R3007989</b>	3007989	Pin, Cylinder Front	5	
84	<b>R3006539</b>	3006539	Bushing	10	
85	<b>R366870</b>	366870	Bushing - Yoke Pivot	10	
86	<b>R366871</b>	366871	Bushing - Pivot - Axle	2	

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.